

## Upper Grill

Stainless steel vertical spokes and crossmembers are welded together at every intersection.

Vertical spokes are made of .2375-in. (.603cm) diameter stainless steel.

Crossmembers are made of .312-in. (.792cm) diameter stainless steel.

Grill is welded to the tubular frame at all contact points to eliminate shifting, racking and rattling.

## Lower Panel

**Lower section of End/Partition Panels is available in four styles:**

- Single-Wall Stainless Steel
- Double-Wall Stainless Steel
- Fiberglass Reinforced Plastic in a choice of colors
- Water-resistant Laminate in a choice of colors

## Frame

All corners have weldnut welded to the inside of the tubing to allow you to disassemble and reassemble pens without loss of structural integrity.

Frame is made of 18-gauge-1.25-in. (3.17cm) square Type 304 stainless steel tubing.

Panel, frame and grill feature a uniform, non-glare, easy-to-clean finish.

46.5-in. (118.11cm) high lower section is securely attached to the tubular frame.

Floor-support Rings offer sturdy floor support with easy cleaning.

Mitered corners and butted joints are heli-arc welded to seal out fluids and debris.

Leg and frame are made of solid, one-piece Type 304 stainless steel tubing.

## Adjustable Floor Levelers

Rear leveler is offset 14-in. (35.56cm) to accommodate a floor trough system.

Levelers adjust to fit irregularities in your floor.

