

"TOTE-AL" SYSTEMIZER EXCHANGE/SUPPLY CARTS,

FEATURES AND BENEFITS

Our Exchange/Supply Carts are designed in two different styles: the Systemizer Cart is designed to support Solid or Wire Shelves, and the Carri Cart is designed to support Solid or Wire Shelves and Drawers.

Support Structure Frame Members are mandrill-bent for wrinkle-free bends.

Shelf Supports are stainless steel rods fully heli-arc circumference-welded, spaced 4" apart. (Optional spacings available upon request.)

Support Structure Frame Members and Chassis are fully heli-arc welded for added strength.

Bottom Deck is one-piece creating a smooth, crevice-free surface.

Four 5" or 8" diameter* Poly-Loc-Poly wheels, plate-mounted swivel casters, copper/nickel plated (two with swivel locks). Swivel and Axle bearings have grease fittings and seals. (Other casters are available.)

Frame Rail and Caster Support Rail members are heli-arc welded creating a one-piece frame that insures continuous, true alignment for easy, smooth maneuvering. Frame design prevents any obstruction of water drainage while washing.

Vinyl inserted, total wraparound design bumper is mounted with brackets to provide clearance between the Bumper and Chassis providing adequate drainage. The Bumper prevents damage to facility walls.

